


Safety First



- The 360 Camera system (option) can assist but note it is disabled at speeds greater than approx. 20mph.
- Familiarize yourself with the location and operation of emergency equipment (fire extinguishers, exits, etc.).
- Never drive if you're feeling fatigued. The Attention Assist (AtA) system can help monitor your alertness by tracking your steering movements and will alert you if it detects signs of drowsiness.




Driving the Tourrider:

- Starting:** Ensure the parking brake is engaged and that the Allison Automatic Transmission™ is in neutral (N) and remember to use ignition key, not the body key, to turn the ignition.
- Retarder:** This is activated using the hand combination switch ('lever') to the right of the steering column. There are 6 positions from 'neutral' at topmost position, initial activation at position 5.1 and increasing when moving switch down until maximum is reached at stage 5 (5.5)
- Switches and Dash Controls:** for a thorough guide on the switches and instrument cluster navigation refer to operator's manual or visit: tourrider.info/service-tips/tourrider-dash-guide



Driver Assistance Systems

- Electronic Brake System (EBS):** Helps with optimal braking and includes ABS (anti-lock braking) and ASR (traction control) functions. These systems are always active.
- Electronic Stability Program (ESP):** Automatically intervenes to maintain stability during skids or swerves by braking individual wheels and reducing engine torque. It can be deactivated using the "TC Off" button on the dashboard, but it's not recommended.
- Active Brake Assist (ABA):** Warns and brakes automatically to avoid collisions with vehicles or pedestrians. It can be turned on or off in the "Systems" "Assistance" submenu the dash.
- Adaptive Cruise Control (ART):** Maintains a set speed and distance from the vehicle ahead. It can be activated and adjusted using the steering wheel buttons. You can set the desired following distance using the controls on right side of the steering wheel.
- Lane Keeping Assist (SPA):** Alerts you if you drift out of your lane by vibrating the corresponding side of the driver's seat. It activates automatically above 37 mph and can be deactivated in the "Systems" "Assistance" submenu.
- Sideguard Assist (SGA):** Warns of objects in your blind spot on the right side using an LED light on the right mirror and seat vibrations. It is always active. Premium will utilize upper mirrors for this feature.




Lavatory and Passenger Comfort

LAV — **Lavatory:** Ensure the lavatory is enabled using the 'LAV' switch on the dashboard. Monitor the waste tank levels through the instrument cluster and empty as needed. Follow steps in Operators Manual or follow QR code for quick guide.



Passenger Seats:

Passengers can adjust their seat backrests [1/2] at Aisle [3] at Window and armrests [4].



Interior Lighting:


Control passenger compartment lighting using the buttons on the dashboard. You can also adjust the reading lights for passengers. Left to right Reading Lamps, Passenger Compartment Lighting Stages, and Night Illumination



HVAC Controls:

12	14	13	
1	2	3	
4	5	6	
7	8	9	
10	11	12	
13	14		
1	Zone Changer (Driver/Pass.)	8	Recirculating Air / Smog Mode
2	Cooling Mode, Driver	9	Auxiliary Heater
3	Cooling Mode, Passenger	10	Roof Ventilators
4	Automatic Control	11	Reheat Mode
5	Air Directional Setting, Driver	12	Temperature Adjustment
6	ON/OFF for Standby Mode	13	Blower Speed Adjustment
7	Defrost Mode	14	HVAC Display

Driver's Seat Adjustment



1. **Seat Cushion Length:** Pull the lever (2) located on the front left side of the seat to slide cushion forward or back.
2. **Seat Cushion Tilt:** Pull the lever (5) on the front right side of the seat cushion and use your body weight to adjust the tilt angle.
3. **Backrest Angle:** While sitting, pull the handle (13) on the right side of the backrest and lean forward or backward to position.
4. **Shoulder Adaptation:** Press button (14) on the upper part of the backrest and use your upper body to adjust the shoulder support.
5. **Reach to Pedals:** Pull lever (1) on the lower left front of the seat and slide the entire seat forward or backward.
6. **Seat Height:** Pull or push handle (6) on the lower right front of the seat to adjust height.
7. **Shock Absorber:** Adjust the firmness by pulling handle (7) up for softer and down for a firmer.
8. **Lumbar Support (Pneumatic):** Use buttons (8) and (9) to inflate or deflate the lower and upper lumbar support air chambers respectively.
9. **Side Bolsters (Pneumatic):** Adjust the side bolster support using button (10).
10. **Armrests (Optional):** If your seat has armrests, you can adjust their inclination by slightly raising them and turning the knob.

11. **Seat Belt Height:** For city buses with a three-point seat belt, adjust the height by pressing the roller (15) and swiveling the belt.
12. **Heating and Ventilation (Optional):** Control seat heating and ventilation (if equipped) using button (11) and adjust the intensity with button (12).


Steering Wheel Adjustment

1. **Unlocking:** Press the switch on the left side of the steering column to disengage the lock. The red LED in the switch will illuminate.
2. **Adjusting:** Adjust the steering wheel to the desired position and angle.
3. **Locking:** Ensure the steering wheel is securely locked in place by pressing the switch again. The red LED should turn off.



Passenger Door Control

- **Open/Close:** Press the button (1) for to open the door. The LED in the button will illuminate, and a symbol will appear on the dash.
- **Troubleshooting:** If the passenger door is malfunctioning, ensure sufficient air pressure and press the 'door reset' button then the passenger door button again.



Braun Wheelchair Lift

Refer to your operator's manual or utilize this link for information on the operation of and resources for the BraunAbility wheelchair lift: tourrider.info/braun

Towing Procedure


Visit tourrider.info/service-tips/towing-prep-procedure or follow the QR code for information on vehicle towing.



TOURRIDER

Drivers Guide

06AM-J004 Rev. 0 | 2024 07 26



DAIMLER TRUCK

Daimler Buses